

G503 WWII Jeep changing of the oil and oil filter

It is not difficult to change the oil and oil filter for your G503 WWII jeep. It can be a little messy, but if your prepared, you can do this yourself and save a little money.

vww.1945gpw.com	Before changing your oil, you want to make sure your oil is warm so that it will drain better. Here in Southern California I will warm engine temp to about 140 degrees or about 10 minutes of idling.
www.1945gpw.com	You will need to a have a catch pan of some sort. Here I have an oil catch pan which will hold about a gallon and half of fluid
www.1945gpw.com	Place the oil catch pan under the oil plug. It gets kind of windy here so I adjust the pan based on the wind and how I estimate it blowing the oil around.

www.1945gpw.com	Remove the oil pan plug by turning the plug counter clock-wise.
www.1945gpw.com	Twist the pan plug with your hand. Try not to drop the plug in the pan, and twist fairly quickly as the oil will start coming out, and depending on how warm your oil is, it can burn you.
www.1945gpw.com	Let the oil drain into the pan. While this is draining, I will head over to the oil fitter and prepare to remove it.
www.1945gpw.com	Remove the oil filter housing lid. Unscrew counter clockwise.

www.1945gpw.com	The oil filter lid will most likely have some oil on it. I will let it drip for a bit before moving it over to a towel for cleaning.
www.1945gpw.com	Here I will put a couple baggies from the grocery store to immediately transfer the old oil filter into it. Trying to avoid spilling oil all over the engine and ground.
www.1945gpw.com	I quickly put the old filter into the baggies, and tie it up for disposal at our approved Oil disposal location here in town.
www.1945gpw.com	You see after taking out the filter you still have about a quart left of oil in the filter housing. You will want to remove this.



vww.1945gpw.com	Remove the old oil filter seal from the lid, and prepare the new seal. I will coat the new seal with a little oil before placing on the lid.
www.1945gpw.com	Clean the lid around the edges thorougly before placing the new seal on. Crud builds up on the edges of the lid, so be sure to wipe it down clean before installing the new seal.
www.rg45gpw.com	New seal installed, now place the lid on the filter housing and tighten up.
www.1945gpw.com	Prior to installing the lid you should inspect the copper washer and replace if needed. These are pretty weak so replacing them is common



